

GAMESIR • GAMING IS WINNING.™

© 2018 GameSir Inc. All rights reserved.  
Product may vary slightly from those pictures.



# GameSir GK300

Wireless Mechanical Gaming Keyboard

User Manual ►

## PRODUCT INTRODUCTION

Important: Please fully charge GameSir GK300 wireless mechanical gaming keyboard before the first use.

## PACKAGE CONTENTS

GameSir GK300 Wireless Mechanical Gaming Keyboard  
Agility X 2.4GHz Wireless Dongle  
Micro-USB Cable (3.28 ft.)  
User Manual

## PRODUCT REQUIREMENTS

Windows 7 (or higher) / macOS / Linux  
Android 4.0 (or higher) / iOS 7.0 (or higher)  
\*PC with USB port



## REGISTRATION

Register your GameSir ID online at <https://gamesir.hk/> to get real-time information on your product's warranty status and a series of exclusive benefits from GameSir.

## YOUR BENEFITS

- \* 12 months limited manufacturer's warranty
- \* Free online technical support at <https://gamesir.hk/> (Supports English and Japanese)

## DEVICE LAYOUT




- A Power switch & LED indicator
- B Forced pairing
- C Windows/macOS switch
- D Media control area
- E Volume control area
- F Lighting effects control area
- G Micro-USB charging port
- H 2.4GHz dongle box
- I Removable palm rest
- J Agility X 2.4GHz wireless dongle
- K Dongle indicator light
- L Micro-USB cable (3.28 ft.)




## CONNECTION

### Connect PC via 2.4GHz wireless dongle

- Switch down to  button, the LED indicator light will flash in green, GameSir GK300 wireless mechanical gaming keyboard is ready to be connected.
- Plug 2.4GHz wireless dongle into Windows PC's USB port, the indicator lights of GameSir GK300 wireless mechanical gaming keyboard and Agility X 2.4GHz wireless dongle will stay green.
- Wait until the LED indicator of GameSir GK300 wireless mechanical gaming keyboard flashes in green. The LED indicator of 2.4GHz wireless dongle will be off after 1 minute. The connection is complete.


**Notice:** If GameSir GK300 wireless mechanical gaming keyboard fails to connect automatically, simultaneously press FN+Reset button for 3 seconds to reconnect.

### Connect PC via Bluetooth 4.2

- Switch up to  button, the LED indicator light will flash in blue, GameSir GK300 wireless mechanical gaming keyboard is ready to be connected.
- Turn on Bluetooth in Windows PC, search GameSir GK300 wireless mechanical gaming keyboard to pair and connect.
- Wait until the LED indicator of GameSir GK300 wireless mechanical gaming keyboard flashes in blue. The connection is complete. GameSir GK300 wireless mechanical gaming keyboard will reconnect to the same PC automatically.

**Notice:** If GameSir GK300 wireless mechanical gaming keyboard fails to connect automatically, simultaneously press FN+Reset button for 1 second to reconnect.





### Connect Android/iOS device via Bluetooth 4.2

- Switch up to  button, the LED indicator light will flash in blue, GameSir GK300 wireless mechanical gaming keyboard is ready to be connected.
- Turn on Bluetooth on your mobile phone, search GameSir GK300 wireless mechanical gaming keyboard to pair and connect.
- Wait until the LED indicator of GameSir GK300 wireless mechanical gaming keyboard flashes in blue. The connection is complete. GameSir GK300 wireless mechanical gaming keyboard will reconnect to the same Android/iOS device automatically.

**Notice:** If GameSir GK300 wireless mechanical gaming keyboard fails to connect automatically, simultaneously press FN+Reset button for 1 second to reconnect.

## MIXSHIFT FUNCTION (FOR PC ONLY)

MixShift function provides a set of FN+N key combination functions including media control and more. It perfectly copes with various daily demands that differ under gaming scenes and optimizes your gaming experiences to the greatest.

MixShift	Features Description
 + 	FN+F7=Volume down
 + 	FN+F8=Volume up
 + 	FN+F9=Mute
 + 	FN+F10=Previous play
 + 	FN+F11=Music play/pause
 + 	FN+F12=Next play
 + 	FN+SL= Switch Windows / macOS
 + 	FN+PB= Reset under wireless mode
 + 	FN+windows=Unlock / lock Windows key
 +  	FN+←/→=Switch lighting effects
 +  	FN+↑/↓=Adjust backlight brightness

## AUTOMATIC POWER OFF / LIGHTING

### 2.4GHz wireless mode

- When GameSir GK300 wireless mechanical gaming keyboard is disconnected under 2.4GHz wireless mode, its backlight will automatically power off within 60 seconds under no operations and be in sleep mode within 120 seconds. Please power on and reconnect.
- When GameSir GK300 wireless mechanical gaming keyboard is connected under 2.4GHz wireless mode, its backlight will automatically dim within 60 seconds under no operations and be in sleep mode within 20 minutes. Press any key to awake the keyboard.

### Bluetooth mode

- When GameSir GK300 wireless mechanical gaming keyboard is disconnected under Bluetooth mode, its backlight will automatically power off within 60 seconds under no operations and be in sleep mode within 120 seconds. Please power on and reconnect.
- When GameSir GK300 wireless mechanical gaming keyboard is connected under Bluetooth mode, its backlight will automatically dim within 60 seconds under no operations and be in sleep mode within 20 minutes. Press any key to awake the keyboard.

## POWER INSTRUCTIONS

### Low power condition

- When GameSir GK300 wireless mechanical gaming keyboard is in low power condition (15% and below), LED indicator will flash quickly in red.
- When GameSir GK300 wireless mechanical gaming keyboard is in low power condition (5% and below), it will automatically power off for power protection.

### Charging statement

- When GameSir GK300 wireless mechanical gaming keyboard is being charged, LED indicator will stay red.
  - When GameSir GK300 wireless mechanical gaming keyboard is fully charged, LED indicator will be off.
- \*Lighting effects of charging indicator and mode indicator have no conflict.

## 日本語

### 製品概要

ご注意:最初に使用する前に、GameSir GK300 ワイヤレス ゲーミングキーボードを完全に充電してください。

### パッケージ内容

GameSir GK300 ワイヤレス ゲーミングキーボード  
2.4GHzドングル (Agility X技術搭載)  
Micro-USBケーブル  
取扱説明書

### システム要件

Windows 7 (以降) / MacOS / Linux  
Android 4.0 (以降) / iOS 7.0 (以降)  
\* 空きのUSBポートを備えるPC



### ユーザー登録

<https://gamesir.hk/>にてGameSir IDを作成して、ご購入の製品を登録すると、当製品の品質保証の状態に関するリアルタイム情報と、GameSir会員専用のメリットを得ることができます。


### 登録による特典

12カ月のメーカー限定保証  
<https://gamesir.hk/>でのマニュアルの閲覧と無料オンラインテクニカルサポート (英語/日本語対応)

## 各部の名称




- A 電源スイッチ&LEDインジケータライト
- B リセットキー
- C PC OS切り替えキー
- D メディアコントロールエリア
- E ボリュームコントロールエリア
- F バックライトコントロールエリア
- G Micro-USB充電端子
- H 2.4GHz Dongle収納ボックス
- I 着脱式パームレスト
- J 2.4GHz Dongle (Agility X技術搭載)
- K 2.4GHz Dongleインジケータライト
- L Micro-USBケーブル



## 機能説明

### 2.4Ghzドングルで PCへの接続

- GameSir GK300 ワイヤレス ゲーミングキーボードを へオンにすると、LEDインジケータライトが緑色で点滅し、GameSir GK300 ワイヤレス ゲーミングキーボードは接続待ち状態に入ります。
- 2.4GhzドングルをPCのUSB端子に差し込むと、LEDインジケータライトと2.4Ghzドングルインジケータライトが緑色で点灯します。
- PCが自動的に対応するドライバをインストールします。ドライバがインストールされると、GameSir GK300 ワイヤレス ゲーミングキーボードが動作できるようになります。  
\* 接続成功する後、LEDインジケータライトが緑色でブリージングし、2.4Ghzドングルインジケータライトが60秒後消灯します。

**ご注意:** GameSir GK300 ワイヤレス ゲーミングキーボードが自動的に接続されない場合は、FN +リセットキーを3秒押ししてリセットする後、もう一度接続してください。

### Bluetooth 4.2で PCへの接続

- GameSir GK300 ワイヤレス ゲーミングキーボードを へオンにすると、LEDインジケータライトが青色で点滅し、GameSir GK300 ワイヤレス ゲーミングキーボードは接続待ち状態に入ります。
- PCのBluetoothをオンにして、GameSir GK300 ワイヤレス ゲーミングキーボードを検索して、接続します。
- LEDインジケータライトが青色で点灯になると、GameSir GK300 ワイヤレス ゲーミングキーボードが動作できるようになります。  
\* 接続成功する後、LEDインジケータライトが青色でブリージングします。

**ご注意:** GameSir GK300 ワイヤレス ゲーミングキーボードが自動的に接続されない場合は、FN +リセットキーを1秒押ししてリセットする後、もう一度接続してください。

### Bluetooth 4.2で Android / iOSへの接続

- GameSir GK300 ワイヤレス ゲーミングキーボードを へオンにすると、LEDインジケータライトが青色で点滅し、GameSir GK300 ワイヤレス ゲーミングキーボードは接続待ち状態に入ります。
- デバイスのBluetoothをオンにして、GameSir GK300 ワイヤレス ゲーミングキーボードを検索して、接続します。
- LEDインジケータライトが青色で点灯になると、GameSir GK300 ワイヤレス ゲーミングキーボードが動作できるようになります。  
\* 接続成功する後、LEDインジケータライトが青色でブリージングします。


**ご注意:** GameSir GK300 ワイヤレス ゲーミングキーボードが自動的に接続されない場合は、FN +リセットキーを1秒押ししてリセットする後、もう一度接続してください。

## MixShift機能(PCのみ)


MixShift	対応機能
 + 	FN+F7=システムボリュームダウン
 + 	FN+F8=システムボリュームアップ
 + 	FN+F9=システムボリュームミュート
 + 	FN+F10=前の曲
 + 	FN+F11=音楽の再生/一時停止
 + 	FN+F12=次の曲
 + 	FN+SL= Windows / MacOS切り替え
 + 	FN+PB= リセット
 + 	FN+windows=Windowsキーのロックオン/ロックオフ
 +  	FN+←/→=バックライト効果を切り替える
 +  	FN+ ↑/↓ =バックライトの明るさを調整する

## 自動休眠

### 2.4GHzモード

- GameSir GK300 ワイヤレス ゲーミングキーボードは2.4Ghzドングル接続なしの状態(接続待ち)で60秒以上操作されないとバックライトがオフになり、120秒以上操作されないと自動的にオフします。
- GameSir GK300 ワイヤレス ゲーミングキーボードは2.4Ghzドングル接続済みの状態で60秒以上操作されないとバックライトが暗くなり、20分以上操作されないと自動的に休眠します。  
\*自動的にオフにしたら、もう一度  :ヘオンにしてください。  
\*自動的に休眠したら、いずれかのキーを押して、休眠が終わります。

### Bluetoothモード

- GameSir GK300 ワイヤレス ゲーミングキーボードがBluetooth 4.2接続なしの状態(接続待ち)で60秒以上接続されないとバックライトがオフになり、120秒以上操作されないと自動的にオフします。
- GameSir GK300 ワイヤレス ゲーミングキーボードがBluetooth 4.2接続済みの状態で60秒以上操作されないとバックライトが暗くなり、20分以上操作されないと自動的に休眠します。  
\*自動的にオフにしたら、もう一度  :ヘオンにしてください。  
\*自動的に休眠したら、いずれかのキーを押して、休眠が終わります。

## バッテリー残量説明

### 残量状態

- バッテリー残量が15%に下回る場合は、バッテリーインジケータライトが速めに赤く点滅します。
- バッテリー残量が5%に下回る場合、自動的に低電力保護状態に入ってシャットダウンします。

### 充電状態

- 充電中ではバッテリーインジケータライトが赤く点灯します。
- 充電完了(100%充電済み)の場合、バッテリーインジケータライトが消灯します。  
\*バッテリーインジケータライトが他のインジケータライトとコンフリクトではありません。



## 简体中文

### 产品简介

重要事项：首次使用前必须先充满电。


### 包装内容



GameSir-GK300游戏机械键盘  
2.4GHz无线接收器  
Micro-USB 数据线(1m)  
说明书  
合格证

### 系统要求

Windows 7 (或更高版本) / MacOS / Linux  
Android 4.0 (或更高版本) / iOS 7.0 (或更高版本)  
\* PC需具有空置USB扩展端口

## 键位布局






- A 电源开关&隐藏式模式指示灯
- B 强制配对键
- C PC系统切换
- D 多媒体控制区
- E 音量控制区
- F 灯效控制区
- G Micro-USB充电接口
- H 2.4GHz接收器收纳仓
- I 可拆卸式掌托 (需另购)
- J Agility X 2.4GHz无线接收器
- K 2.4GHz无线接收器指示灯
- L Micro-USB数据线 (1m)


## 连接方式

### 通过2.4Ghz无线接收器连接PC

- a. 将开关向下拨动至 ，此时隐藏式模式指示灯闪烁绿光，GameSir-GK300无线游戏机械键盘进入2.4GHz连接等待状态。
- b. 将2.4Ghz无线接收器插入Windows PC的USB端口，此时连接状态指示灯和Agility X2.4GHz无线接收器状态灯点亮绿光。
- c. 稍等片刻，GameSir-GK300无线游戏机械键盘可以正常使用。连接成功后5秒隐藏式模式指示灯为呼吸绿光，2.4GHz无线接收器指示灯将在常亮一分钟后熄灭。


注意：如未自动进行连接，请同时按住FN键+强制配对键（PB键）3秒，重新进行配对。

### 通过4.2蓝牙连接PC

- a. 将开关向上拨动至 ，此时隐藏式模式指示灯闪烁蓝光，GameSir-GK300无线游戏机械键盘进入蓝牙等待连接状态。
- b. 开启PC蓝牙，搜索GameSir-GK300并将其添加至配对列表。
- c. 稍等片刻，GameSir-GK300无线游戏机械键盘可以正常使用。连接成功5秒后隐藏式模式指示灯为呼吸蓝光。再次连接同一PC时将自动连接。

注意：如未自动进行连接，请同时按住FN键+强制配对键（PB键）1秒，重新进行配对。

### 通过4.2蓝牙连接安卓/iOS设备

- a. 将开关向上拨动至 ，此时隐藏式模式指示灯闪烁蓝光，GameSir-GK300无线游戏机械键盘进入蓝牙连接等待状态。
- b. 开启安卓/iOS设备的蓝牙，搜索GameSir-GK300并将其添加至配对列表。
- c. 稍等片刻，GameSir-GK300无线游戏机械键盘可以正常使用。连接成功5秒后隐藏式模式指示灯为呼吸蓝光。再次连接同一PC时将自动连接。

注意：如未自动进行连接，请同时按住FN键+强制配对键（PB键）1秒，重新进行配对。


## MixShift功能按键

MixShift功能将提供多媒体控制等多种FN+N的键位组合功能，完美处理日常不同类型的场景的各种需求，最大化你的游戏体验。


MixShift	功能
 + 	FN+F7=系统声音减少
 + 	FN+F8=系统声音增加
 + 	FN+F9=系统声音静音
 + 	FN+F10=上一首音乐
 + 	FN+F11=音乐播放/暂停
 + 	FN+F12=下一首音乐
 + 	FN+SL= windows/MacOS切换
 + 	FN+PB= 无线模式进入强制全新配对
 + 	FN+windows=开启与锁定windows键
 +  	FN+←/→=切换按键灯效
 +  	FN+↑/↓=调节背光亮度

## 自动休眠

### 2.4Ghz模式

- 当GameSir-GK300游戏机械键盘处于2.4GHz无线模式未连接状态时，无操作情况下将于60秒后自动关闭背光，120秒后自动休眠，此时请重新开机  进行连接。
- 当GameSir-GK300游戏机械键盘处于2.4GHz无线模式连接状态时，无操作情况下将于60秒后背光自动变为弱光状态，20分钟后自动休眠。此时请按下一按键进行唤醒。

### 蓝牙模式

- 当GameSir-GK300游戏机械键盘处于蓝牙模式未连接状态时，无操作情况下将于60秒后自动关闭背光，120秒后自动休眠，此时请重新开机  进行连接。
- 当GameSir-GK300游戏机械键盘处于蓝牙模式连接状态时，无操作情况下将于60秒后背光自动变为弱光状态，20分钟后自动休眠。此时请按下一按键进行唤醒。

## 电量说明

### 低电量模式

- 当GameSir-GK300游戏机械键盘电量低于15%时，隐藏式模式指示灯为快速闪烁红光。
- 当GameSir-GK300游戏机械键盘电量低于5%时，将自动关机进入电量保护状态。

### 充电模式

- 当GameSir-GK300游戏机械键盘处于充电状态时，隐藏式模式指示灯为常亮红光。
- 当GameSir-GK300游戏机械键盘充电完成时，红光将熄灭。

注：充电模式指示灯与其他模式指示灯不冲突。

## 关于符合中国《电子信息产品污染控制管理办法》的声明

产品名称：游戏键盘

产品型号：GameSir-GK300



部件名称	有害物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(CR (VI) )	多溴联苯(PBB)	多溴二苯醚(PBDE)
外壳	○	○	○	○	○	○
字键模组	○	○	○	○	○	○
电路板组件	○	○	○	○	○	○
连接线及配件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。

○：表示该有害物质在该部件所有均质材料中含量均在GB/T 26572规定的限量要求以下。

X：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。

表中标有“X”的所有部件都符合欧盟RoHS法规“关于电子电器设备中限制使用某些有害物质的2011/65/EU指令”

注：环保使用期限的参考标识取决于产品正常工作的温度和湿度等条件。

中国环保材料内容宣布-仅适用于中国

## NOTICE: Please read this Precautions carefully.

- CONTAINS SMALL PARTS. Keep out of reach of children under the age of 3. Seek immediate medical attention if swallowed or inhaled.
- DO NOT use the product near fire.
- DO NOT expose to direct sunlight or high temperatures.
- DO NOT leave the product in a humid or dusty environment.
- DO NOT impact the product or cause it to fall due to strong impact.
- DO NOT touch USB port directly or it might cause malfunctions.
- DO NOT strongly bend or pull cable parts.
- Use a soft, dry cloth while cleaning.
- DO NOT use chemicals such as gasoline or thinner.
- DO NOT disassemble, repair or modify.
- DO NOT use for purposes other than its original purpose. We are NOT responsible for accidents or damage when used for non-original purposes.
- DO NOT look directly at the optical light. It might damage your eyes.
- If you have any quality concerns or suggestions, please contact GameSir or your local distributor.

**⚠️ ご注意:保護者の方へ必ずお読みください。**

- 小さいな部品がありますので3歳未満のお子様には絶対に与えないでください。
- 乳幼児の手の届くところに置かないでください。万一飲み込んだ場合は、すぐに医師に相談してください。
- 火気のある場所では絶対に使用しないでください。
- 長時間直射日光当てたり、高温となる場所に置かないでください。
- 本品を湿気やホコリの多いところに置かないでください。
- 本品に物を当てたり、落下させるような強い衝撃を与えないでください。
- 故障の原因になりますので、USB端子を直接手で触らないでください。
- ケーブル部を強く曲げたり引っ張ったりしないでください。
- お手入れの際には、乾いた柔らかい布を使用してください。
- ベンジン、シンナーなどの薬品は使用しないでください。
- 分解や修理、改造は絶対にしないでください。
- 本来の目的以外には使用しないでください。本来の目的以外に使用した場合の事故や損害に対し、弊社は一切その責任を負いません。
- 光学式ライトの光を直接見ないでください。強い光より、目を痛める可能性があります。

\* 品質上の問題または提案がある場合に販売元またはアフターサービス担当者に連絡してください。

**⚠️ 注意事項**

1. 若商品有质量问题，请首先联系我们的客服进行登记。

联系方式:

QQ: 800082537

电话: 400-8828035 (时间: 9: 00-18: 00)

官网: www.xiaoji.com

出品: 广州小鸡快跑网络科技有限公司

地址: 广州市天河区建业路华翠街68号301A-1

2. 如需退、换商品，请确保商品完好无损（包括商品外包装、附赠品、说明书、售后卡、标签等），不影响二次销售。

3. 如要保修商品，请务必完整填写用户姓名、联系电话、联系地址，正确填写售后要求与详细说明售后原因，将售后卡随货寄回（如不完整填写保修卡信息，恕无法提供任何售后服务。）

## 保修卡

(售后政策：非人为损坏，3个月包换、1年保修)

用户姓名

联系电话

联系地址

售后要求

退 换 保修

售后原因

订单编号

(注：非小鸡官网途径购买的产品，售后问题请直接与购买商家联系)

